



*Item 2 inserts into item 1. **Emne nr. 2 passer ind i emne nr. 1. *Objekt 2 wordt in object 1 gebracht. *Osa 2 asetetaan osan 1 sisään. *La placa 2 doit être insérée dans la pièce 1. *Die Batteriefeder 2 in die Endkappe 1 stecken. *Inserire il pezzo 2 nel pezzo 1. *Del 2° set in ins in del 1° *O item 2 deve ser inserido no item 1. *Inserite pieza 2 dentro de la pieza 1. *Artikl 2 förs in artikl 1. **Do not disassemble. **Älmötnar icke. **Niet demonteren. **Älä pura. **Ne pas désassembler. **Nicht entfernen. **Non smontare. **Ikkä demonteer. **Näo demontar. **No desarmar. **No ita islar

Function Sets Chart • Skema over funktionsindstillinger • Tabel met functieseries • Toinimittien asetusten luetelo • Tableau des ensembles de fonctions • Funktionstabelle • Diagramma dei Set di Funzione • Översikt over funktionssett • Modos de operação quadro • Tabla de conjuntos de funciones • Tabell över funktionsuppsättningar

Table with 4 columns (GENERAL, OUTDOOR, LAW ENFORCEMENT, TACTICAL) and 3 rows (1 CLICK, 2 CLICKS, 3 CLICKS) showing various flashlight settings.

ENGLISH - Thank you for purchasing a Mag-Lite® flashlight product. To register your new Mag® flashlight visit our website at www.maglite.com, from our home page just go to "Register Your Maglite®". To view the entire product line click on "Products". Please review all the information contained in this pamphlet.

OPERATION: Large end of battery spring must be snapped into tailcap. Always install batteries with the "+" end facing the head end of the flashlight and the "-" end facing the tailcap end of the flashlight. Switch - Push button switch. Flood to Spot - Rotate head of flashlight to adjust from a wide flood beam to an intense spotlight.

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

EXCLUSIONS: This warranty does not cover: 1. Dead batteries, battery leakage or explosion; 2. LED failure; or 3. Product damage due to alteration, misuse, battery leakage or lack of maintenance. MAG DISCLAIMS ANY RESPONSIBILITY FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES.

HOW AND WHEN TO MAKE A WARRANTY CLAIM: 1. In case of dead batteries, replace batteries; do not send batteries or flashlight to Mag. 2. If a flashlight is damaged by battery leakage, determine what brand of battery caused the damage and follow the battery manufacturer's instructions regarding damage claims;

As it comes out of the package, your MAGLITE® LED flashlight is set to the "Standard" function set (Function Set #1 in the chart). If you require only those three functions (Full Power, Low Power and Eco), then you never have to change it. You can select a function within that set by the "Quick Click" method.

How To Go From One Function Set To Another Your MAGLITE® LED flashlight's "standard" setting is Function Set #1. If you want to keep that setting you don't have to do anything. Function Set #1 will always be in effect unless it is changed. If you want to choose a different function set, follow these steps:

- 1. Unscrew the tail cap (you may not have to remove it all the way; you only need to back it out of the barrel enough that the flashlight will not turn out).
- 2. Pause for 2 seconds.
- 3. Press the switch button and keep holding it down.
- 4. While still holding down the switch button, screw the tail cap back in until it is tight.

TROUBLESHOOTING: If flashlight does not turn on or stay on - 1. Replace the batteries. If the problem persists, then 2. Check the tail cap. The metal surfaces contacting the barrel, tail cap and spring assembly should be clean, shiny and free of corrosion or other obstruction. Clean as needed.

WARNINGS: • TO AVOID RISK OF EYE INJURY, LOOK AWAY IMMEDIATELY IF BEAM IS SHONE DIRECTLY INTO YOUR EYES. • AVOID EXPOSING BATTERIES TO FIRE OR EXCESSIVE HEAT as this may result in battery leakage or explosion.

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

vælger du funktionsgruppe #2, efter 3 blink, vælger du funktionsgruppe #3, og efter 4 blink, vælger du funktionsgruppe #4). Dit valg af en funktionsgruppe forbliver aktivert indtil du ændrer det ved at gentage processen beskrevet overfor.

Utsultningen af de funktioner i gruppe #1 er standard. Hvis du kun vil have disse tre funktioner (fuld effekt, lav effekt og øko), behøver du aldrig at ændre indstillingen. Du kan vælge en funktion inden for denne gruppe ved hjælp af "hurtig klik"-metoden.

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

met de "Snelklik" methode: Schakel de zaklamp aan met een snelklik en hij staat op Krachtige. Schakel hem uit en terug aan met twee snelklikken (ongeveer zo snel als men "klik klik" zegt) om de zaklamp in te stellen op - de Lage-Functie. Schakel hem uit en terug aan in drie snelklikken (ongeveer zo snel als men "klik klik klik" zegt) om de zaklamp in te stellen op de Eco-Functie.

En functie selecteren binnen een andere functieset werkt op dezelfde manier; met een, twee, of drie snelklikken zoals weergegeven in de tabel. U bevindt zich bijvoorbeeld in functieset #2 en u wenst de Flichslichtmodus functie te selecteren; begin dan met de zaklamp uit, klik drie keer snel en uw zaklamp geeft het Flichslichtmodus.

Veranderen van functieset Uw MAGLITE® LED zaklamp is standaard ingesteld op functieset #1. Wilt u deze instelling behouden, dan hoeft u niets te doen. Functieset #1 werkt altijd, tenzij deze wordt veranderd. Wilt u een andere functieset instellen, ga dan als volgt te werk:

- 1. Draai de schroefloep los (de dop hoeft er niet af, alleen losdraaien zodat de zaklamp niet aanschakelt).
- 2. Wacht 2 seconden.
- 3. Druk op de schakelaar en houd deze ingedrukt.
- 4. Houd de schakelaar ingedrukt en schroef de dop er terug op tot deze vast zit.

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

rapidement, et votre lampe enverra le stroboscopes. Comment passer d'un groupe de fonctions à un autre Le réglage « standard » de votre lampe MAGLITE® LED est le groupe de fonctions n°1. Si vous souhaitez garder ce réglage, vous n'avez rien à faire. Le groupe de fonctions n°1 sera toujours actif si vous ne changez rien les réglages. Pour choisir un autre groupe de fonctions, procédez comme suit :

- 1. Dévissez le capuchon (il n'est pas nécessaire de le retirer complètement ; il suffit de le dévisser juste assez pour que la lampe ne s'allume pas).
- 2. Attendez 2 secondes.
- 3. Appuyez sur l'interrupteur et maintenez-le enfoncé.
- 4. Tout en maintenant l'interrupteur, revissez le capuchon en place, jusqu'à ce qu'il soit bien serré.

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

How To Choose A Function Within a Set The available function sets, and the functions within each one, are shown in the following table:

